

MX-1408 Self-Contained



Adjustable, Folding Handle

Folds for convenient storage or transport and is adjustable for operators comfort when cleaning.

Accessory Quick-Connect

For use with optional accessories for cleaning upholstery, stair, and in hard to reach areas.

specifications

MX-1408 (338583)

Cleaning Path:

14" w/2 Forward and 2 Reverse
Spray Jets

Vacuum Motor:

120Volt, 1.9 HP - 112 CFM
Waterlift 106"

Brush Motor: 0.5 HP; 2.3 AMPS

Brush Speed: 675 RPM

Water Output:

1.8 GPM (Adjustable)

Pump Pressure: 100 PSI

Capacity Shared:

8 Gallon Solution and Recovery

Power Cord:

25 Ft, 3 Wire Grounded, Plus
25 Ft Extension Cord

Optional Accessories:

15 Ft Solution Hose (408263)

Wand & Nozzle Assembly
w/2 Spray Jets (408271)

Upholstery Tool (379468)



Tank drains fully.

Using a floor drain or the supplied plastic bucket.

MX-1408 extractor is compact and easy to operate. There are no external solution lines, hoses or separate wand to deal with, they are self-contained. It is excellent for cleaning carpeted areas in hotels, offices, stores, restaurants, and many other facilities.

Brush assisted forward/reverse action allows for the extractor to clean carpet fibers in "both" directions for more effective cleaning while reducing labor time and effort.

Features

Trigger Lever

Squeeze the trigger to operate in reverse.

Control Switches

Located at operators finger tips, clearly illustrate and sealed to protect against moisture.

25 Ft Power Cord

Wraps around, quick release cord holder on back of handle for storage.

See-Thru Dome

Allow for constant monitoring of the extractors cleaning effectiveness.

Shared 8 Gal Chamber Solution/Recovery System

Holds solution in a bladder and it is pumped out for the cleaning operation. As the bladder empties dirty solution is vacuumed up and recovered in the commonly shared tank.

Kick Stand

Lifts brush off the floor to protect it when not in use.

2 Sets of 2 Spray Nozzles

Operate independently, spraying ahead of the brush when cleaning in either direction. Solution volume can be adjusted using a directional valve.

Vacuum Shoes

Provide continuous forward and reverse suction recovering dirty solution in either direction.